

recap




Melody Generator

Melody generator using BT66 IC



Introduction


Melody generator using BT66IC





Required Components


- Breadboard
- Buzzer
- BT66 IC
- Resistor
- Snap Connector
- Jumper Wires
- Battery 9v



Snap Connector




Buzzer





BT66 IC


- The BT66T is an easy to use 3 terminal Melody generator IC.
- This IC is easy to use because it can work on low voltage (0.3V to 3.5V) and consumes very little current (1uA) during operation.
- It's applications are:
 - Used to play melody
 - Make project more attractive using sound
 - Notify users through a melody
 - Used in Toys, Calling Bells, Alarms, etc.






Procedure

Connection Steps






Place breadboard






• Connect snap connector to 9v battery and keep it aside






• Insert BT66 IC in breadboard






Connection Step 4

• Insert resistor to the output terminal of the IC as shown in the sconnection diagram.






• Insert buzzer in the breadboard.






• Connect cathode(-) terminal of battery to (-) power rail of breadboard.






• Connect cathode(-) terminal of buzzer to the (-) power rail of breadboard.






Connection Step 8

• Connect cathode(-) terminal of IC to (-) power rail of breadboard.






• Connect anode(+) terminal of IC to (+) power rail of breadboard.






• Connect open terminal of resistor to anode (+) pin of buzzer.






• Connect anode(+) terminal of battery to (+) power rail of breadboard.






Connection Step 12

Connect upper power rail of breadboard to lower power rail by
Connecting (+) to (+) and (-) to (-) rails as shown in the figure.





• Make sure your connections are made as per the diagram





Data & Outcomes

Learning from the activity



• Use BT66 IC

Melody generation



• Using BT66 IC for melody generation.



Assessment



Thank you